




SEW
EURODRIVE



Synchronous Compact Servomotors CMD55/70/93/138

GB250000

Edition 05/2005

11302410 / EN

Operating Instructions





1	Important Information on Operating Instructions.....	4
1.1	Important information and designated use.....	4
1.2	Explanation of the icons.....	5
2	Safety Instructions.....	6
3	Unit Design	7
3.1	Unit designation and nameplates.....	7
3.2	Design of CMD synchronous compact servomotor.....	9
4	Mechanical Installation.....	10
4.1	Required tools / aids	10
4.2	Before you begin, make sure that:	10
4.3	Preliminary work	10
4.4	Installing the motor.....	12
4.5	Installation tolerances	12
5	Electrical Installation	13
5.1	Connector installation	13
5.2	Wiring instructions.....	14
5.3	Connecting the motor and encoder system via plug connectors	15
5.4	Installation of resolver / HIPERFACE® plug connectors	23
5.5	Power connector installation	26
5.6	Standard equipment.....	29
6	Startup.....	31
6.1	Prerequisites for startup.....	31
7	Malfunctions	32
7.1	Motor problems	32
7.2	Malfunctions when operating with a servo controller	32
8	Inspection / Maintenance	33
8.1	Inspection intervals	33
9	Technical Data.....	34
9.1	CMD motor data.....	34
9.2	Thermal classifications and enclosure types of the motor	56
9.3	CMD dimensions.....	57
9.4	Inverter assignment MOVIDRIVE® MDX60B/61B	61
9.5	External radial and axial shaft loads	63
10	Appendix.....	66
10.1	Appendix A: Abbreviations and unit designations.....	66
11	Index.....	67



1 Important Information on Operating Instructions

1.1 Important information and designated use

Integral part of the product

The operating instructions are part of the CMD synchronous compact servomotor and contain important information for operation and service. The operating instructions are written for assembly, installation, startup and service employees who are involved in the installation and maintenance of CMD synchronous compact servomotors.

Designated use

The designated use refers to the procedure specified in the operating instructions.

CMD synchronous compact servomotors are drive motors for use in industrial and commercial systems. Motor utilizations other than that specified and areas of application other than industrial and commercial systems can only be used after consultation with SEW-EURODRIVE.

CMD synchronous compact servomotors meet the requirements set forth in the Low-Voltage Directive 73/23/EEC. You must not take the machinery into operation in the designated fashion until you have established that the end product complies with the Machinery Directive 98/37/EC.

Qualified personnel

CMD synchronous compact servomotors represent a potential hazard for persons and material. Consequently, assembly, installation, startup and service work may only be performed by trained personnel who are aware of the potential hazards.


The personnel must be appropriately qualified for the task in hand and must be familiar with the assembly, installation, startup and operation of the product. The personnel must read the operating instructions, in particular the safety notes section, carefully and ensure that they understand and comply with them.

Liability for defects

Incorrect handling or any action performed that is not specified in these operating instructions could impair the properties of the product. In this case, you lose any right to claim under limited warranty against SEW-EURODRIVE GmbH & Co KG.

Product names and trademarks

The brands and product names contained within these operating instructions are trademarks or registered trademarks of the titleholders.



1.2 Explanation of the icons



Hazard

Indicates an imminently hazardous situation which, if not avoided, **WILL** result in death or serious injury.



Warning

Indicates an imminently hazardous situation caused by the product which, if not avoided, **WILL** result in death or serious injury. You will also find this signal to indicate the potential for damage to property.



Caution

Indicates a potentially hazardous situation which, if not avoided, **MAY** result in minor injury or damage to products.



Note

Indicates a reference to useful information, e.g. on startup.



Documentation reference

Indicates a reference to a document, such as operating instructions, catalog, data sheet.



2 Safety Instructions

General information



The following safety instructions are primarily concerned with the use of CMD synchronous compact servomotors.

If using **gear units**, also refer to the safety instructions for gear units in the corresponding operating instructions.



Danger of burns!

Touching the CMD synchronous compact servomotor when it has not been cooled will result in burns. **The motor may have a surface temperature of over 100 °C.**

Never touch the CMD synchronous compact servomotor during operation or in the cool down phase once it has been switched off.



3 Unit Design

3.1 Unit designation and nameplates

Example: Synchronous compact servomotor CMD93M / KTY / RH1M / SM11


Nameplate on the motor



54900ADE

Figure 1: Nameplate: CMD synchronous compact servomotor

Unit designation






Unit Design

Unit designation and nameplates

Serial number





3.2 Design of CMD synchronous compact servomotor



The following illustration is intended to explain the general structure. It serves as an assignment aid to the spare parts list. Discrepancies are possible depending on the motor size and version.




Figure 2: Basic design of the CMD synchronous compact servomotor

54768AXX

- [1] Rotor
- [7] Flanged end shield
- [11] Grooved ball bearing
- [16] Stator
- [42] Non drive-end bearing shield
- [44] Grooved ball bearing
- [105] Equalizing ring
- [304] Housing cover
- [305] Resolver
- [313] Signal plug connector
- [318] Power plug connector



4 Mechanical Installation



It is essential to comply with the safety instructions in Sec. 2 during installation.

4.1 Required tools / aids

- Standard tool
- Crimping tool for plug connectors, used for self-fabrication
- For conversion of the connector, removal tool for insulating elements

4.2 Before you begin, make sure that:

- The entries on the nameplate of the drive and/or the output voltage of the frequency inverter match the voltage supply system.
- The drive is undamaged (no damage caused by transportation or storage).
- The ambient temperature is between -20 °C and +40 °C.
- No oil, acid, gas, vapors, radiation, etc.
- The altitude does not exceed 1000 m above sea level, otherwise the drive must be configured in accordance with the special ambient conditions.

4.3 Preliminary work

Motor shaft ends must be thoroughly cleaned of anti-corrosion agents, contamination or similar. Use a commercially available solvent for this purpose. Do not allow the solvent to penetrate the bearings or shaft seals, since this could cause material damage.

4.3.1 Extended storage of motors

- Please note the reduced grease utilization period of the ball bearings after storage periods exceeding one year.
- Check whether the motor has absorbed moisture as a result of being stored for a long time. Measure the insulation resistance to do this (measuring voltage DC 500 V).



The insulation resistance varies greatly depending on the temperature, refer to Figure 3.
The motor must be dried if the insulation resistance is not adequate.




Figure 3: Insulation resistance depending on the temperature

53725AXX

4.3.2 Drying the motor



Insulation resistance too low:

→ Motor has absorbed moisture.

Action: Send the motor to SEW-EURODRIVE Service with a description of the error.



4.4 Installing the motor



The motor may only be mounted in the specified position on a level, vibration-free and torsionally rigid support structure. The mounting position must dissipate heat in order for the rated power to be achieved.



Danger of burns!

Touching the CMD synchronous compact servomotor when it has not been cooled will result in burns. **The motor may have a surface temperature of over 100 °C.**

Never touch the CMD synchronous compact servomotor during operation or in the cool down phase once it has been switched off.

Carefully align the motor and the driven machine to avoid placing any unacceptable strain on the output shafts. Observe the permitted overhung load and axial load.

Do not butt or hammer the shaft end.

Use a half key to balance components with a keyway for subsequent mounting on the shaft. Motor shafts are balanced with a half key if necessary.

4.4.1 Installation in damp locations or in the open

- If possible, arrange the motor and encoder connection so the connector cables are not pointing upwards.
- Carefully clean the connectors (motor or encoder connection) before reinstalling.
- Install new gaskets to replace brittle ones.
- Restore the anticorrosion coating if necessary.
- Check the enclosure.

4.5 Installation tolerances

Shaft end	Flanges
Diameter tolerance in accordance with DIN 748 • ISO k6 • Center hole in accordance with DIN 332	Centering shoulder tolerance in accordance with DIN EN 50347 • ISO j6



5 Electrical Installation



It is essential to comply with the safety instructions in Sec. 2 during installation.

Switch contacts in utilization category AC-3 to EN 60947-4-1 must be used for switching the motor.

When motors are powered from inverters, you must adhere to the wiring instructions issued by the inverter manufacturer. It is essential to observe the operating instructions for the servo controller.

5.1 Connector installation



Incorrect installation can result in connector damage!

Tightening the connector in the incorrect insertion position causes the insulating element to come unclipped, leading to permanent damage.

Note the following when plugging in the power and signal connectors:

- Correct insertion position
- The locking lug must be in the correct position.
- It must be possible to turn the connector locking device without needing to apply great force.




5.2 Wiring instructions

5.2.1 EMC-compliant installation

Note the following points.

All cables except for the power supply line must be **shielded**. As an alternative to the shield, the HD.. option (output choke) can be used for the motor cable in order to comply with the interference emission limit values.

Connect the **shield by the shortest possible route and make sure it is grounded over a wide area at both ends**. You can ground one end of the shield via a suppression capacitor (220 nF / 50 V) to avoid ground loops. If using double-shielded cables, ground the outer shield on the inverter end and the inner shield on the other end.



00755BXX

Figure 4: Correct shield termination using metal clamp (shield clamp) or metal cable gland

You can also use **grounded sheet-metal ducts or metal pipes to shield the cables**. **Route the power and control cables separately.**

For detailed information on EMC compliant installation, refer to the publication "Electromagnetic Compatibility in Drive Engineering" from SEW-EURODRIVE.

5.2.2 Protection against interference from motor protection devices

Only separately shielded feeder cables and sensor feeder cables are allowed to be routed together with switch-mode power lines in one cable. This is in order to protect against interference from motor protection devices of type KTY or optionally TF.

Do not route unshielded feeder cables together with switched-mode power lines in one cable.



5.3 Connecting the motor and encoder system via plug connectors

CMD synchronous compact servomotors are supplied with the SM.. / RM.. plug connector system. In the basic version, SEW-EURODRIVE delivers CMD synchronous compact servomotors with flange-mounting socket on the motor end and without mating connector. The encoder system is connected using a 12-pin round plug connector.

The cable entry of the power and signal cables is via plug connectors. The direction of the plug connectors is defined in the order.

5.3.1 Line cross section

Make sure the type of line corresponds to the applicable regulations. The rated currents are specified on the motor nameplate. The line cross sections that can be used are listed in the following tables.

Type	Connector	Cable type	Line cross section
SM10 / SM11	Right-angle connector	Motor cable	4 x 1.5 mm ²
RM10 / RM11	Radial connector	Motor cable	4 x 1.5 mm ²

Power plug connectors

Motor type	Plug connector system	Plug connector	Socket contact
CMD55 ... 138	SM10	Delivered without mating connector	4 x 1.5 mm ²
CMD55 ... 138	SM11	BSTA078FR14080035056	4 x 1.5 mm ²

Signal plug connector

Resolver / encoder and thermal motor protection

Plug connector	Socket contact
Mating connector ASTA021FR18620035064	10 x 0.25 mm ²
Mating connector ASTA021FR18620035064	10 x 0.25 mm ²

5.3.2 Pre-fabricated cables

Pre-fabricated cables are available from SEW-EURODRIVE to connect the SM.. / RM.. plug connector systems. The core designation and contact assignment are listed in the following tables.

The plug connectors are depicted with the connector assignment on the cable at the connection side (back).

Please note the following if you are fabricating your cables yourself:

- Assembly of the signal plug connector is described in Sec. 5.4.
- The socket contacts for the motor connection are implemented as crimping contacts. Use only suitable tools for crimping.
- Strip the insulation from the leads in accordance with Sec. 5.4. Apply shrink tubing to connectors.
- Use only suitable removal tools to remove incorrectly installed socket contacts.



Electrical Installation

Connecting the motor and encoder system via plug connectors

5.3.3 CMD synchronous compact servomotor wiring diagrams

The following applies to all wiring diagrams:

- View to the wiring side
- Colors according to SEW-EURODRIVE cable:

Color code	Color
BK	Black
BN	Brown
BU	Blue
GN	Green
GY	Gray
OG	Orange
PK	Pink
RD	Red
VT	Violet
WH	White
YE	Yellow
GY/PK	Gray / pink
RD/BU	Red / blue
BK/WH	Black / white
RD/WH	Red / white

Plug connectors




Figure 5: SM.. plug connector drawn without pins Angled connector variant for CMD55/70/93 54903AEN





Figure 6: SM.. plug connector without pins drawn for CMD138

54890AXX




Figure 7: RM.. plug connector drawn without pins. Straight connector variant for
CMD55/70/93/138

54891AXX




Electrical Installation

Connecting the motor and encoder system via plug connectors

5.3.4 CMD motor cable

Design of motor cable



54068AXX


Figure 8: CMD motor cable (power)

- [1] Connector: Intercontec BSTA 078
- [2] Printed on connector: SEW-EURODRIVE Bruchsal
- [3] Nameplate
- [4] Line length ≤ 10 m: +200 mm tolerance
Line length ≥ 10 m: +2 % tolerance
Permitted line length according to the technical documents
- [5] Prefabricated cable end for inverter
Required loose parts are supplied with the cable
- [6] Shielding 20 mm, pulled back approximately + 5 mm

Loose parts

SEW-EURODRIVE supplies a bag of loose parts in accordance with the core cross sections for connection to the power terminals on the inverter.

Bag no.	Contents
1	4 x conductor end sleeves 1.5 mm ² , insulated 4 x M6 U-shaped cable lugs 1.5 mm ²
2	4 x conductor end sleeves 2.5 mm ² , insulated 4 x M6 U-shaped cable lugs 2.5 mm ²
3	4 x conductor end sleeves 4 mm ² , insulated 4 x M6 U-shaped cable lugs 4 mm ² 4 x M10 U-shaped cable lugs 4 mm ²



Pin assignment of the motor cables


Installation	Part number	
Fixed routing	0590 454 4	LAPP TPE/CY 303 027 1
Cable carrier installation	0590 477 3	NEXANS PSL11YC11-J 493 080 60

Plug connector	Contact	Core identification	Assigned
BSTA 078 View X	1	(BK) Black	U
	2	(GN/YE) Green / yellow	PE
	3	(BK) Black	W
	4	(BK) Black	V

5.3.5 Resolver cables

Resolver cable for MOVIDRIVE® MDX60B/61B

Design of resolver cable for MOVIDRIVE® MDX60B/61B



54110AXX

Figure 9: Resolver cable for MOVIDRIVE® MDX60B/61B

- [1] Connector: Intercontec ASTA 021
- [2] Printed on connector: SEW-EURODRIVE Bruchsal
- [3] Nameplate
- [4] Line length ≤ 10 m: +200 mm tolerance
Line length ≥ 10 m: +2 % tolerance
Permitted line length according to the technical documents
- [5] 9-pin sub D connector





Electrical Installation

Connecting the motor and encoder system via plug connectors

Pin assignment of cable for RH1M resolver for MOVIDRIVE® MDX60B/61B

Installation	Part number	
Fixed routing	199 487 5	LAPP TPE/CY 303 042 0
Cable carrier installation	199 319 4	NEXANS 493 266 70

Plug connector	Contact	Core identification	Assigned	Contact	Connection type
ASTA 021 FR 198 673 2 12-pin with socket contacts  View X	1	(PK) Pink	R1 (reference +)	3	Sub D plug 9-pole  View Y
	2	(GY) Gray	R2 (reference -)	8	
	3	(RD) Red	S1 (cosine +)	2	
	4	(BU) Blue	S3 (cosine -)	7	
	5	(YE) Yellow	S2 (sine +)	1	
	6	(GN) Green	S4 (sine -)	6	
	7	n.c.	—	—	
	8	n.c.	—	—	
	9	(BN) Brown (VT) Violet	KTY+ (TF)	9	
	10	(WH) White (BK) Black	KTY- (TF)	5	
	11	n.c.	—	—	
	12	n.c.	n.c.	4	


5.3.6 Encoder cables

The following notes must be observed when connecting the HIPERFACE® AS0H / ES0H / AS1H / ES1H encoder:

- Only use shielded cables with twisted pair conductors.
- Connect the shield to the PE potential on both ends over a large surface area.
- Route signal cables separately from power cables or brake cables (min. distance 200 mm).



Do not disconnect the signal plug connector of the HIPERFACE® encoder AS1H / ES1H when live.




**Encoder cable for
MOVIDRIVE®
MDX60B/61B**

The following section only applies to motor size CMD93 ... 138.

For operation with MOVIDRIVE® MDX60/61B, the encoder is connected via plug connector depending on motor type and motor design (see following figures, the colors correspond to the color code for SEW-EURODRIVE cables).

Connect the HIPERFACE® encoder to MOVIDRIVE® MDX60/61B as follows.

Design of HIPERFACE® cable for MOVIDRIVE® MDX60B/61B



54087AXX

Figure 10: Design of HIPERFACE® cable for MOVIDRIVE® MDX60B/61B

- [1] Connector: Intercontec ASTA 021
- [2] Printed on connector: SEW-EURODRIVE Bruchsal
- [3] Nameplate
- [4] Length is order-specific in ± 200 meter steps
- [5] 15-pin sub D connector





Electrical Installation

Connecting the motor and encoder system via plug connectors

Pin assignment of HIPERFACE® cable for encoder AS1H / ES1H for MOVIDRIVE® MDX60B/61B

Installation	Part number	
Fixed routing	199 488 3	LAPP TPE/CY 303 028 1
Cable carrier installation	199 320 8	NEXANS 493 290 70


Plug connector	Contact	Core identification	Assigned	Contact	Connection type
ASTA 021 FR 198 673 2 12-pin with socket contacts  View X	1	n.c.	n.c.	3	Sub D plug 15-pole  View Y
	2	n.c.	n.c.	5	
	3	(RD) Red	S1 (cosine +)	1	
	4	(BU) Blue	S3 (cosine –)	9	
	5	(YE) Yellow	S2 (sine +)	2	
	6	(GN) Green	S4 (sine –)	10	
	7	(VT) Violet	Data –	12	
	8	(BK) Black	Data +	4	
	9	(BN) Brown	KTY+ (TF)	14	
	10	(WH) White	KTY– (TF)	6	
	11	(GY/PK) Gray / pink (PK) Pink	GND	8	
	12	(RD/BU) Red / blue (GY) Gray	US	15	
	–	–	n.c.	7	
	–	–	n.c.	11	
	–	–	n.c.	13	



5.4 Installation of resolver / HIPERFACE® plug connectors

5.4.1 Scope of supply for resolver / HIPERFACE® plug connectors

The following parts are supplied for installing resolver / HIPERFACE® plug connectors.
The SEW part number is 198 673 2.



- [1] Fitting
- [2] Seal with strain relief
- [3] Shield ring
- [4] Socket contacts
- [5] Insulating sleeve
- [6] Insulating element
- [7] Connector housing










Hold the cable firmly when you are tightening the cable and the plug.




Electrical Installation

Installation of resolver / HIPERFACE® plug connectors

5.4.2 Installation instructions for resolver / HIPERFACE® plug connectors

1		Pull the screw fitting and the seal with strain relief 31 mm over the cable.
2		Strip 28 mm cable insulation off the end of the cable.
3		Lay the braid shield backwards and fan it out.
4		- Strip 6 mm insulation off the leads. - Push the socket contacts onto the ends of the leads.
5		- Insert the small-diameter positioning tool (SEW part number 019 244 9) into the crimping tool until the green mark appears in viewing aperture [A]. - Set press thickness [B] to 24 on the crimping tool.
6		- Insert a lead with socket contact into the crimping tool and press the crimping tool together fully. The tool then opens automatically. - Repeat this procedure for each lead.
7		Guide the shield ring over the leads and press the shield against the seal.




8		Turn the shield ring until the braid shield is flush with the shield ring.
9		Pull the insulating element apart evenly by 1 mm.
10		Insert the socket contacts into the insulating elements according to the wiring diagrams in Sec. 5.3.
11		Press the insulating elements together until the "click".
12		- Fold open the insulating sleeve. - Position the side of the insulating sleeve with the recess against the groove in the insulating element so that the opening in the insulating sleeve is pointing in the same direction as the double-headed arrow on the insulating element. - Then press the insulating sleeve together until it engages. - Insert the insulating element into the connector housing in the middle position.
13		- Brace the connector housing using a wrench and use a second wrench to tighten the screw fitting. [A] = Brace



5.5 Power connector installation

5.5.1 Scope of delivery of power connectors

The following parts are supplied for installing the power connectors. The SEW part number is 198 674 0.




56252AXX








- [1] Fitting
- [2] Seal with strain relief
- [3] Shield ring
- [4] Socket contacts
- [5] Insulating sleeve
- [6] Insulating element
- [7] Connector housing



Hold the cable firmly when you are tightening the cable and the plug.



5.5.2 Power connector installation instructions

1		• Pull the screw fitting and the seal with strain relief over the cable.															
2		• Strip 59 mm cable insulation off the end of the cable.															
3		• Lay the braid shield backwards and fan it out.															
4		• Shorten the power leads (1, 2 and 3) to 44 mm. • Shorten the PE lead (GN/YE) to 45 mm. • Do not shorten lead pair 5 and 6. • Cut off lead pair 7 and 8 flush with the end of the cable.															
5		• Guide the shield ring over the leads. • Strip 7 mm of insulation off leads 1, 2, 3 and PE. • Strip 5 mm of insulation off leads 5 and 6.															
6		• Insert the positioning tool in the crimping tool until the marking (color) appears in viewing aperture [A] (see table below). • Set press thickness [B] on the crimping tool according to the table. <table><tr><th>Lead</th><th>a [mm²]</th><th>Positioning tool Part number xxx xxx x</th><th>Marking (Color)</th><th>Press thickness</th></tr><tr><td>5 and 6</td><td>0.14 ... 1.0</td><td>019 244 9</td><td>Green (GN)</td><td>24</td></tr><tr><td>1, 2, 3 and PE</td><td>0.35 ... 4.0</td><td>019 245 7</td><td>Blue (BU)</td><td>6</td></tr></table>	Lead	a [mm ²]	Positioning tool Part number xxx xxx x	Marking (Color)	Press thickness	5 and 6	0.14 ... 1.0	019 244 9	Green (GN)	24	1, 2, 3 and PE	0.35 ... 4.0	019 245 7	Blue (BU)	6
Lead	a [mm ²]	Positioning tool Part number xxx xxx x	Marking (Color)	Press thickness													
5 and 6	0.14 ... 1.0	019 244 9	Green (GN)	24													
1, 2, 3 and PE	0.35 ... 4.0	019 245 7	Blue (BU)	6													
7		• Insert a lead with socket contact into the crimping tool and press the crimping tool together fully. The tool then opens automatically. • Repeat this procedure for each lead in accordance with the table in step 6.															



Electrical Installation

Power connector installation

8		Open the insulating sleeve.
9		- Insert the middle socket contact into the insulating element according to the wiring diagram in Sec. 5.3. - Close the insulating sleeve until the "click". - Insert the remaining socket contacts into the insulating elements according to the wiring diagram in Sec. 5.3.
10		- Shorten the braid shield as shown. - Insert the shield ring into the seal so that the shield and the end of the cable are flush. Make sure the braid shield is routed cleanly between the shield ring and seal.
11		Insert the insulating element into the connector housing until the seal is located against its stop in the connector housing.
12		- Brace the connector housing using a wrench and use a second wrench to tighten the screw fitting. [A] = Brace



5.6 Standard equipment



Connect the supplied optional equipment according to the wiring diagrams in Sec. 5.3.



Possible damage to the motor winding!

Due to the low thermal time constant of the winding, thermistor-type protection of CMD servomotors is only provided if current monitoring (I^2t -, r.m.s. current monitoring) or a motor model like in SEW inverters is activated, in addition to the KTY temperature sensor or the TF temperature sensor.

5.6.1 KTY temperature sensor type KTY84 ... 130




Possible damage to the temperature sensor as well as the motor winding!

Avoid currents > 4 mA in the circuit of the KTY sensor since excessively high self-heating of the temperature sensor can damage its insulation and the motor winding.

It is absolutely essential to observe the correct connection of the KTY to ensure a correct evaluation of the temperature sensor.

The characteristic curve in the following figure shows the resistance curve with a measuring current of 2 mA and a correct polarity connection.



50927AXX

Figure 11: Resistance depending on the temperature

Refer to the pin assignments of the resolver / encoder cables for precise information about connecting the KTY. Please make sure the polarity is correct.



Thermistor-type motor protection in conjunction with the KTY sensor is provided by a thermal motor model in the servo controller. The thermistor-type motor protection function is exclusively available with the MOVIDRIVE[®] MDX60B / 61B servo controller.



5.6.2 TF temperature sensor option

Thermistor-type motor protection in conjunction with TF is not 100 % assured due to the response time of the PTC semiconductor, in particular with small, highly dynamic servomotors. As a result, SEW-EURODRIVE advises using only KTY sensors for thermistor-type motor protection in conjunction with MOVIDRIVE® MDX60B / 61B. Please contact SEW-EURODRIVE if you would like to use TF temperature sensors for thermistor-type motor protection with CMD servomotors.



Possible damage to the temperature sensor as well as the motor winding!

An excessively high input voltage at the temperature sensor can damage its insulation as well as the motor winding, and may cause irreparable damage to the semiconductor.


Make sure the connection to a TF evaluation unit is correct.

Do not apply a voltage > 10 V!

The positive temperature coefficient (PTC) thermistors comply with DIN 44082.

Resistance measurement (measuring instrument with $U = 2.5 \text{ V}$ or $I < 1 \text{ mA}$):

- Standard measured values: $20 \dots 500 \Omega$, thermal resistance $> 4000 \Omega$



6 Startup

6.1 Prerequisites for startup



It is essential to comply with the safety notes in Sec. 2 during startup.

6.1.1 Before startup

- The drive must be undamaged and is not allowed to be blocked.
- The measures stipulated in Sec. 4.3 "Preliminary work" must be performed after extended storage.
- All connections must have been made properly.
- The direction of rotation of the motor / gearmotor must be correct.
- All protective covers must have been fitted correctly.
- All motor protection devices must be active.
- No other sources of danger are allowed to be present.
- No materials which are sensitive to high temperatures and no thermally insulating materials are allowed to cover the motor surface.

6.1.2 During startup

- The motor must run correctly (no overload, no inadvertent speed fluctuation, no loud noises, etc.).
- In case of problems, first refer to Sec. 7 "Malfunctions."



7 Malfunctions

7.1 Motor problems

Problem	Possible cause	Remedy
Motor does not start up	Interruption in connecting lead	Check connections, correct if necessary
	Fuse blown	Replace fuse
	Motor protection has tripped	Check motor protection for correct setting, correct error if necessary.
Incorrect direction of rotation	Motor connected incorrectly	Check inverter, check setpoints
Motor hums and has high current consumption	Drive is blocked	Check drive
	Fault on encoder cable	Check encoder cable
Motor heats up excessively (measure temperature, significantly above 110 °C)	Overload	Perform power measurement, use larger motor or reduce load if necessary
	Ambient temperature is too high	Adhere to permitted temperature range
	Rated operation type (S1 to S10, EN 60034) exceeded, e.g. through excessive r.m.s. torque	Adjust rated operation type of motor to required operating conditions; if necessary call in a specialist to determine correct drive
Running noise on motor	Bearing damage	- Consult with SEW-EURODRIVE customer service - Replace the motor

7.2 Malfunctions when operating with a servo controller



The symptoms described in Sec. 7.1 "Motor problems" may also occur when the motor is operated with a servo controller. Please refer to the servo controller operating instructions for the significance of the problems which occur and to find information about rectifying the problems.

Please have the following information to hand if you require the assistance of our customer service:

- Data from the nameplate (complete)
- Nature and extent of the fault
- Time and peripheral circumstances of the fault
- Presumed cause



8 Inspection / Maintenance

Use only genuine spare parts in accordance with the valid parts list.

Disconnect the motor from the power supply before starting work and protect it against unintentional re-start.




Danger of burns!

Touching the CMD servomotor when it has not been cooled will result in burns. **The motor may have a surface temperature of over 100 °C.**

Never touch the CMD synchronous compact servomotor during operation or in the cool down phase once it has been switched off.

8.1 Inspection intervals

The periods of wear are affected by many factors and may be short. The machine designer must calculate the required inspection intervals individually in accordance with the project planning documents (e.g. Drive Engineering - Practical Implementation – Drive Project Planning, Geared Servomotors catalog).



9 Technical Data

9.1 CMD motor data

Motor type	$n_N^{1)}$ [rpm]	M_0 [Nm]	I_0 [A]	M_{max} [Nm]	I_{max} [A]	R_1 [Ω]	L_1 [mH]	V_{p0} [rpm]	J [kgcm ²]	m [kg]	n_{max} [rpm]
CMD 55 S	4500	0.25	0.7	1.2	4	28.65	28.4	26	0.076	0.9	8000
CMD 55 M		0.45	0.95	2.3	6	18.44	21.6	33	0.15	1.2	8000
CMD 55 L		0.9	1.5	6	12	10.18	14.8	39	0.3	1.7	8000
CMD 70 S	3000	0.7	1.04	3	6	17.44	32.3	43	0.21	1.4	6000
CMD 70 M		1.1	1.36	5	8	10.89	25.2	56	0.4	1.9	5000
CMD 70 L		1.9	1.96	11	18	5.85	17.0	64	0.76	2.7	5000
CMD 93 S	1200	2.4	1.55	10	8	10.64	43.0	93	1.16	3.2	2750
CMD 93 M		4.2	2.5	22	16	3.63	19.1	110	2.25	4.7	2750
CMD 93 L		6	3.5	33	23	3.14	18.0	106	3.35	6.3	2750
CMD 93 S	3000	2.4	2.32	10	12	4.60	19.2	62	1.16	3.2	4000
CMD 93 M		4.2	3.6	22	23	2.27	9.3	77	2.25	4.7	4000
CMD 93 L		6	6	33	40	1.02	6.0	61	3.35	6.3	4000
CMD 138 S	1200	6.7	3.9	17	13	1.97	25.0	117	6.5	8.4	2500
CMD 138 M		12.1	5.5	39	26	1.29	20.6	148	12.4	12.1	2000
CMD 138 L		16.5	8	62	40	0.66	11.8	138	18.1	15.8	2000
CMD 138 S	2000	6.7	7.4	17	25	0.60	7.0	62	6.5	8.4	3000
CMD 138 M		12.1	11.4	39	53	0.30	4.8	71	12.4	12.1	2000
CMD 138 L		16.5	15.1	62	76	0.20	3.3	73	18.1	15.8	2000


1) n_N = Rated speed [rpm]



M_0 is the thermal continuous torque for speeds between 5 and 200 rpm.
 The permitted continuous torque at standstill is 90 % of M_0 .

9.1.1 Torque-current characteristic

Torque-current characteristic CMD55




55988AXX

Figure 12: Torque-current characteristic CMD55

- [1] CMD55S
- [2] CMD55M
- [3] CMD55L


Torque-current characteristic CMD70



55990AXX

Figure 13: Torque-current characteristic CMD70

- [1] CMD70S
- [2] CMD70M
- [3] CMD70L



Torque-current characteristic CMD93




Figure 14: Torque-current characteristic CMD93

55991AXX

- [1] CMD93S
- [2] CMD93M
- [3] CMD93L

Torque-current characteristic CMD138





Figure 15: Torque-current characteristic CMD138

55995AXX

- [1] CMD138S
- [2] CMD138M
- [3] CMD138L

9.1.2 Dynamic limit characteristic curves

Dynamic limit characteristic curve CMD55S $n_N = 4500 \text{ min}^{-1}$




55919AXX

Figure 16: Dynamic limit characteristic curve CMD55S $n_N = 4500 \text{ min}^{-1}$


- [1] M_{S1} (derating)
- [2] $M(I_{\max}, n)$ 360 V
- [3] $M(I_{\max}, n)$ 400 V
- [4] $M(I_{\max}, n)$ 460 V
- [5] $M(I_{\max}, n)$ 500 V



The input voltage of the inverter is always specified.



Dynamic limit characteristic curve CMD55M $n_N = 4500 \text{ min}^{-1}$



55920AXX


Figure 17: Dynamic limit characteristic curve CMD55M $n_N = 4500 \text{ min}^{-1}$

- [1] M_{S1} (derating)
- [2] $M(I_{\max}, n)$ 360 V
- [3] $M(I_{\max}, n)$ 400 V
- [4] $M(I_{\max}, n)$ 460 V
- [5] $M(I_{\max}, n)$ 500 V



The input voltage of the inverter is always specified.

Dynamic limit characteristic curve CMD55L $n_N = 4500 \text{ min}^{-1}$




55925AXX

Figure 18: Dynamic limit characteristic curve CMD55L $n_N = 4500 \text{ min}^{-1}$


- [1] M_{S1} (derating)
- [2] $M(I_{\max}, n)$ 360 V
- [3] $M(I_{\max}, n)$ 400 V
- [4] $M(I_{\max}, n)$ 460 V
- [5] $M(I_{\max}, n)$ 500 V



The input voltage of the inverter is always specified.



Dynamic limit characteristic curve CMD70S $n_N = 3000 \text{ min}^{-1}$



55963AEN


Figure 19: Dynamic limit characteristic curve CMD70S $n_N = 3000 \text{ min}^{-1}$

- [1] M_{S1} (derating)
- [2] $M(I_{\max}, n)$ 360 V
- [3] $M(I_{\max}, n)$ 400 V
- [4] $M(I_{\max}, n)$ 460 V
- [5] $M(I_{\max}, n)$ 500 V



The input voltage of the inverter is always specified.

Dynamic limit characteristic curve CMD70M $n_N = 3000 \text{ min}^{-1}$




55966AXX

Figure 20: Dynamic limit characteristic curve CMD70M $n_N = 3000 \text{ min}^{-1}$


- [1] M_{S1} (derating)
- [2] $M(I_{max}, n)$ 360 V
- [3] $M(I_{max}, n)$ 400 V
- [4] $M(I_{max}, n)$ 460 V
- [5] $M(I_{max}, n)$ 500 V



The input voltage of the inverter is always specified.



Dynamic limit characteristic curve CMD70L $n_N = 3000 \text{ min}^{-1}$



55968AXX

Figure 21: Dynamic limit characteristic curve CMD70L $n_N = 3000 \text{ min}^{-1}$

- [1] M_{S1} (derating)
- [2] $M(I_{\max}, n)$ 360 V
- [3] $M(I_{\max}, n)$ 400 V
- [4] $M(I_{\max}, n)$ 460 V
- [5] $M(I_{\max}, n)$ 500 V



The input voltage of the inverter is always specified.

Dynamic limit characteristic curve CMD93S $n_N = 1200 \text{ min}^{-1}$





Figure 22: Dynamic limit characteristic curve CMD93S $n_N = 1200 \text{ min}^{-1}$

55973AXX

- [1] M_{S1} (derating)
- [2] $M(I_{max}, n)$ 360 V
- [3] $M(I_{max}, n)$ 400 V
- [4] $M(I_{max}, n)$ 460 V
- [5] $M(I_{max}, n)$ 500 V



The input voltage of the inverter is always specified.



Dynamic limit characteristic curve CMD93S $n_N = 3000 \text{ min}^{-1}$




Figure 23: Dynamic limit characteristic curve CMD93S $n_N = 3000 \text{ min}^{-1}$

55982AXX

- [1] M_{S1} (derating)
- [2] $M(I_{\max}, n)$ 360 V
- [3] $M(I_{\max}, n)$ 400 V
- [4] $M(I_{\max}, n)$ 460 V
- [5] $M(I_{\max}, n)$ 500 V



The input voltage of the inverter is always specified.

Dynamic limit characteristic curve CMD93M $n_N = 1200 \text{ min}^{-1}$





Figure 24: Dynamic limit characteristic curve CMD93M $n_N = 1200 \text{ min}^{-1}$

55976AXX


- [1] M_{S1} (derating)
- [2] $M(I_{\max}, n)$ 360 V
- [3] $M(I_{\max}, n)$ 400 V
- [4] $M(I_{\max}, n)$ 460 V
- [5] $M(I_{\max}, n)$ 500 V



The input voltage of the inverter is always specified.



Dynamic limit characteristic curve CMD93M $n_N = 3000 \text{ min}^{-1}$



55985AXX


Figure 25: Dynamic limit characteristic curve CMD93M $n_N = 3000 \text{ min}^{-1}$

- [1] M_{S1} (derating)
- [2] $M(I_{max}, n)$ 360 V
- [3] $M(I_{max}, n)$ 400 V
- [4] $M(I_{max}, n)$ 460 V
- [5] $M(I_{max}, n)$ 500 V



The input voltage of the inverter is always specified.

Dynamic limit characteristic curve CMD93L $n_N = 1200 \text{ min}^{-1}$




55979AXX

Figure 26: Dynamic limit characteristic curve CMD93L $n_N = 1200 \text{ min}^{-1}$


- [1] M_{S1} (derating)
- [2] $M(I_{\max}, n)$ 360 V
- [3] $M(I_{\max}, n)$ 400 V
- [4] $M(I_{\max}, n)$ 460 V
- [5] $M(I_{\max}, n)$ 500 V



The input voltage of the inverter is always specified.



Dynamic limit characteristic curve CMD93L $n_N = 3000 \text{ min}^{-1}$



55987AXX


Figure 27: Dynamic limit characteristic curve CMD93L $n_N = 3000 \text{ min}^{-1}$

- [1] M_{S1} (derating)
- [2] $M(I_{\max}, n)$ 360 V
- [3] $M(I_{\max}, n)$ 400 V
- [4] $M(I_{\max}, n)$ 460 V
- [5] $M(I_{\max}, n)$ 500 V



The input voltage of the inverter is always specified.

Dynamic limit characteristic curve CMD138S $n_N = 1200 \text{ min}^{-1}$





55948AXX

Figure 28: Dynamic limit characteristic curve CMD138S $n_N = 1200 \text{ min}^{-1}$

- [1] M_{S1} (derating)
- [2] $M(I_{\max}, n)$ 360 V
- [3] $M(I_{\max}, n)$ 400 V
- [4] $M(I_{\max}, n)$ 460 V
- [5] $M(I_{\max}, n)$ 500 V



The input voltage of the inverter is always specified.


Dynamic limit characteristic curve CMD138S $n_N = 2000 \text{ min}^{-1}$


55960AXX

Figure 29: Dynamic limit characteristic curve CMD138S $n_N = 2000 \text{ min}^{-1}$

- [1] M_{S1} (derating)
- [2] $M(I_{max}, n)$ 360 V
- [3] $M(I_{max}, n)$ 400 V
- [4] $M(I_{max}, n)$ 460 V
- [5] $M(I_{max}, n)$ 500 V



The input voltage of the inverter is always specified.

Dynamic limit characteristic curve CMD138M $n_N = 1200 \text{ min}^{-1}$





Figure 30: Dynamic limit characteristic curve CMD138M $n_N = 1200 \text{ min}^{-1}$

55955AXX


- [1] M_{S1} (derating)
- [2] $M(I_{max}, n)$ 360 V
- [3] $M(I_{max}, n)$ 400 V
- [4] $M(I_{max}, n)$ 460 V
- [5] $M(I_{max}, n)$ 500 V



The input voltage of the inverter is always specified.



Dynamic limit characteristic curve CMD138M $n_N = 2000 \text{ min}^{-1}$



55961AXX


Figure 31: Dynamic limit characteristic curve CMD138M $n_N = 2000 \text{ min}^{-1}$

- [1] M_{S1} (derating)
- [2] $M(I_{\max}, n)$ 360 V
- [3] $M(I_{\max}, n)$ 400 V
- [4] $M(I_{\max}, n)$ 460 V
- [5] $M(I_{\max}, n)$ 500 V



The input voltage of the inverter is always specified.

Dynamic limit characteristic curve CMD138L $n_N = 1200 \text{ min}^{-1}$




55959AXX

Figure 32: Dynamic limit characteristic curve CMD138L $n_N = 1200 \text{ min}^{-1}$


- [1] M_{S1} (derating)
- [2] $M(I_{max}, n)$ 360 V
- [3] $M(I_{max}, n)$ 400 V
- [4] $M(I_{max}, n)$ 460 V
- [5] $M(I_{max}, n)$ 500 V



The input voltage of the inverter is always specified.



Dynamic limit characteristic curve CMD138L $n_N = 2000 \text{ min}^{-1}$




55962AXX

Figure 33: Dynamic limit characteristic curve CMD138L $n_N = 2000 \text{ min}^{-1}$

- [1] M_{S1} (derating)
- [2] $M(I_{max}, n)$ 360 V
- [3] $M(I_{max}, n)$ 400 V
- [4] $M(I_{max}, n)$ 460 V
- [5] $M(I_{max}, n)$ 500 V



The input voltage of the inverter is always specified.



9.1.3 Derating for increased ambient temperature

The following applies to determining a first approximation of a random thermal limit curve: The thermal limit curve for higher ambient temperatures must be reduced in all points (limit torque with reference to speed) by ΔM_{TH} :

$$\Delta M_{TH} = M_{TH} \times \left(1 - \sqrt{\frac{145 - T_U}{105}} \right)$$

$$M_{TH_re} = M_{TH} - \Delta M_{TH}$$

Example CMD 93L with $n_N = 3000 \text{ min}^{-1}$:

$$T_U = 60 \text{ }^\circ\text{C}$$

$$M_{TH} = 5 \text{ Nm}$$

$$n = 2500 \text{ min}^{-1}$$

$$\Delta M_{TH} = 5 \times \left(1 - \sqrt{\frac{145 - 60}{105}} \right) \text{ Nm}$$


$$\Delta M_{TH} = 0.5 \text{ Nm}$$

$$M_{TH_re} = 5.0 \text{ Nm} - 0.5 \text{ Nm} = 4.5 \text{ Nm}$$

ΔM_{TH}	Thermal limit torque [Nm] difference
M_{TH}	Thermal limit torque [Nm]
T_U	Ambient temperature [$^\circ\text{C}$]
M_{TH_re}	Reduced thermal limit torque [Nm]

9.1.4 Derating for high installation altitudes

No reduction in the thermal limit torque is required at installation altitudes up to 2000 m. For operation at altitudes above 2000 m above sea level, please contact SEW-EURODRIVE.



Technical Data

Thermal classifications and enclosure types of the motor

9.2 Thermal classifications and enclosure types of the motor

Thermal classifications according to IEC 60034-1 (EN 60034-1)

CMD series motors are delivered with thermal classification F as standard.

The following table lists the overtemperatures to IEC 60034-1 (EN 60034-1).


Thermal class	Overtemperature limit [K]
B	80 K
F ¹⁾	105 K
H	125 K

1) Motor standard

Enclosure types according to EN 60034 (IEC 60034-5)

CMD series motors are delivered with enclosure type IP65 as standard.


IP	1st digit Protection against foreign objects	2nd digit Protection against water
0	No protection	No protection
1	Protection against solid foreign objects Ø 50 mm and larger	Protection against dripping water
2	Protection against solid foreign objects Ø 12 mm and larger	Protection against dripping water when tilted up to 15°
3	Protection against solid foreign objects Ø 2.5 mm and larger	Protection against spraying water
4	Protection against solid foreign objects Ø 1 mm and larger	Protection against splashing water
5	Protection against dust	Protection against water jets
6	Dust-proof	Protection against powerful water jets
7	–	Protection against temporary immersion in water
8	–	Protection against permanent immersion in water



9.3 CMD dimensions

CMD55..

08 029 00 04




55327AXX

	CMD55S..	CMD55M..	CMD55L..
L	107	125	160
LB	82	100	135
st ¹⁾	9 ... 14	9 ... 14	9 ... 14
st_1 ²⁾	5.5 ... 14	5.5 ... 14	5.5 ... 14

1) Round connector, power

2) Round connector, signal


CMD70..
08 030 00 04


55328AXX

	CMD70S..	CMD70M..	CMD70L..
L	121	139	174
LB	91	109	144
st ¹⁾	9 ... 14	9 ... 14	9 ... 14
st ₁ ²⁾	5.5 ... 14	5.5 ... 14	5.5 ... 14


1) Round connector, power

2) Round connector, signal



CMD93..

08 031 00 04



55329AXX


	CMD93S..	CMD93M..	CMD93L..
L	144	179	219
LB	104	139	174
st ¹⁾	9 ... 14	9 ... 14	9 ... 14
st ₁ ²⁾	5.5 ... 14	5.5 ... 14	5.5 ... 14

1) Round connector, power


2) Round connector, signal

CMD138..**08 032 00 04**

/RM..



/SM..




55330AXX

	CMD138S..	CMD138M..	CMD138L..
L	179	214	249
LB	121	156	191
st ¹⁾	9 ... 14	9 ... 14	9 ... 14
st ₁ ²⁾	5.5 ... 14	5.5 ... 14	5.5 ... 14

1) Round connector, power

2) Round connector, signal




9.4 Inverter assignment MOVIDRIVE® MDX60B/61B

Sizes 0 and 1

Motor type	n _N [rpm]	M ₀ [Nm]	Inverter I _{max} [A]	Size 0				Size 1			
				0005 4	0008 4.8	0011 6.2	0014 8	0015 6	0022 8.25	0030 10.5	0040 14.25
			I _{max} [A]	Peak torque [Nm]							
CMD 55 S	4500	0.25	4	1.2							
CMD 55 M		0.45	6	1.8	2.0	2.3					
CMD 55 L		0.9	12	2.5	2.9	3.7	4.5	3.6	4.6	5.4	5.9
CMD 70 S	3000	0.7	6	2.2	2.5	3					
CMD 70 M		1.1	8	3.2	3.7	4.5	5	4.4	5		
CMD 70 L		1.9	18	3.8	4.5	5.8	7.4	5.7	7.6	9.1	10.6
CMD 93 S	1200	2.4	8	5.8	6.7	8.1	10	7.9	10		
CMD 93 M		4.2	16		8.2	10.5	13.3	10.2	13.6	16.6	20.6
CMD 93 L		6	23			10.5	13.5	10.1	14.0	17.6	23.1
CMD 93 S	3000	2.4	12		4.8	6.0	7.3	5.8	7.5	8.8	10
CMD 93 M		4.2	23				9.5	7.2	9.8	12.3	15.9
CMD 93 L		6	40								13.9
CMD 138 S	1200	6.7	13						12.8	15.2	17
CMD 138 M		12.1	26							21.9	27.9
CMD 138 L		16.5	40								
CMD 138 S	2000	6.7	25								11.9
CMD 138 M		12.1	53								
CMD 138 L		16.5	76								

Values in *italics*

Maximum torque M_{max} (limited by maximum motor current I_{max})
approximately. 3 times M_0



Technical Data

Inverter assignment MOVIDRIVE® MDX60B/61B

Sizes 2 and 3

Motor type	n _N [rpm]	M ₀ [Nm]	Inverter I _{max} [A]	Size 2			Size 3		
				0055 18.75	0075 24	0110 36	0150 48	0220 69	0300 90
			I _{max} [A]	Peak torque [Nm]					
CMD 55 S	4500	0.25	4						
CMD 55 M		0.45	6						
CMD 55 L		0.9	12						
CMD 70 S	3000	0.7	6						
CMD 70 M		1.1	8						
CMD 70 L		1.9	18	11					
CMD 93 S	1200	2.4	8						
CMD 93 M		4.2	16	22					
CMD 93 L		6	23	28.6	33				
CMD 93 S	3000	2.4	12						
CMD 93 M		4.2	23	19.5	22				
CMD 93 L		6	40	18.1	22.5	30.7	33		
CMD 138 S	1200	6.7	13						
CMD 138 M		12.1	26	33.3	37.8	39			
CMD 138 L		16.5	40	36.8	45.0	59.0	62		
CMD 138 S	2000	6.7	25	14.7	17				
CMD 138 M		12.1	53		23.7	31.8	37.2	39	
CMD 138 L		16.5	76			37.4	47.1	59.6	62

Values in *italics*

Maximum torque M_{max} (limited by maximum motor current I_{max})
approximately. 3 times M₀

9.5 External radial and axial shaft loads

The permitted overhung loads at point x (distance from the shaft shoulder to the application point) are determined using the diagrams below. The diagrams are based on a nominal bearing service life of $L_{10h} = 20,000$ h.




Figure 34: Representation of overhung load F_R and axial load F_A

05590AXX

CMD55





Figure 35: CMD55, permitted overhung load F_R at point x

54913AXX

Permitted axial load (F_A) at average speed $n = 1000$ rpm: $F_A = 120$ N.


Permitted axial load (F_A) at average speed $n = 2000$ rpm: $F_A = 80$ N.



Technical Data

External radial and axial shaft loads

CMD70




54914AXX

Figure 36: CMD70, permitted overhung load F_R at point x

Permitted axial load (F_A) at average speed $n = 1000 \text{ rpm}$: $F_A = 215 \text{ N}$.

Permitted axial load (F_A) at average speed $n = 2000 \text{ rpm}$: $F_A = 150 \text{ N}$.

CMD93




54922AXX

Figure 37: CMD93, permitted overhung load F_R at point x

Permitted axial load (F_A) at average speed $n = 1000 \text{ rpm}$: $F_A = 165 \text{ N}$.

Permitted axial load (F_A) at average speed $n = 2000 \text{ rpm}$: $F_A = 110 \text{ N}$.

CMD138



54923AXX

Figure 38: CMD138, permitted overhung load F_R at point x

Permitted axial load (F_A) at average speed $n = 1000$ rpm: $F_A = 265$ N.

Permitted axial load (F_A) at average speed $n = 2000$ rpm: $F_A = 285$ N.



10 Appendix

10.1 Appendix A: Abbreviations and unit designations

Abbreviation	Definition
BSF	Helical-bevel servo gear unit [Engl.: B evel S ervo F lange]
DIN	D eutsches I nstitut für N ormung e.V. [Engl.: German Standardization Group]
EN	E uropäische N orm [Engl.: European standard]
ISO	I nternational O rganization for S tandardization
SW	S chlüsselweite [Engl.: wrench size]
PSF	Planetary gear unit [Engl.: P lanetary S ervo F lange]
M_0 [Nm]	Thermal continuous torque for speeds between 5 and 200 rpm
M_{S1}	Permitted continuous torque for speeds above 200 rpm
I_0 [Nm]	Continuous current
$M_{\max}$ [Nm]	Maximum torque
$I_{\max}$ [Nm]	Maximum current
M_N [Nm]	Rated torque
n_N [rpm]	Rated speed
$n_{\max}$ [rpm]	Maximum speed
R_1	Ohmic phase resistance of the stator winding
L_1	Phase inductance
V_{p0}	Rotor voltage (induced voltage, EMF)
J	Rotor mass moment of inertia
m	Weight (of the motor)
F_R [N]	Permitted overhung load
F_A [N]	Permitted axial load



11 Index

A

Abbreviations	66
AC motors	
<i>Enclosure types</i>	56
<i>Thermal classes</i>	56

C

Cables	
<i>Encoder</i>	20
<i>Motor</i>	18
<i>Pre-fabricated cables</i>	15
<i>Resolver</i>	19
Connection of motor and encoder system via plug connectors	15
Connector installation	13
Cool down phase	12

D

Derating	55
Design CMD synchronous compact servomotor ...	9
Dimensions	57

E

Electrical installation	13
Enclosure types	56
Encoder cables	20
Equipment	29
Explanation of the icons	5
Extended storage of motors	10
External radial and axial shaft loads	63

I

Important information	4
Inspection	33
Inspection intervals	33
Installation	
<i>Electrical</i>	13
<i>Mechanical</i>	10
Installation of connectors	13
Installation tolerances	12
Installing the motor	12
Instructions, wiring	14
Insulation resistance	11
Inverter assignment	
MOVIDRIVE® MDX60B/61B	61

L

Line cross section	15
Loose parts bag, motor cable	18

M

Maintenance	33
Malfunctions	32
Malfunctions, operating with a servo controller ...	32
Mechanical installation	10

Motor cables	18
<i>Loose parts bag</i>	18
<i>Pin assignment</i>	19
Motor data	34
Motor problems	32

N

Nameplate	7
-----------------	---

P

Pin assignment of the motor cables	19
Plug connector installation	23
Plug connectors	
<i>Installation</i>	23
<i>Power plug connector</i>	15
<i>RM.. plug connector</i>	17
<i>Signal plug connector</i>	15
<i>SM.. plug connector</i>	16, 17
Power connector installation	26
Power connectors	
<i>Installation</i>	26
Power plug connector	15
Pre-fabricated cables	15
Preliminary work	10
Problems	32
Problems with the motor	32

R

Resolver cables	19
-----------------------	----

S

Safety and warning instructions	6
Serial number	8
Signal plug connector	15
Standard equipment	29
Startup	31
Storage, extended	10

T

Technical data	34
Thermal classifications	56
thermischen Grenzkurve	55
Tools	10

U

Unit designation	7
------------------------	---

W

Wiring diagrams	16
Wiring instructions	14



Address List

Germany			
Headquarters Production Sales	Bruchsal	SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 42 D-76646 Bruchsal P.O. Box Postfach 3023 · D-76642 Bruchsal	Tel. +49 7251 75-0 Fax +49 7251 75-1970 http://www.sew-eurodrive.de sew@sew-eurodrive.de
Service Competence Center	Central Gear units / Motors	SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 1 D-76676 Graben-Neudorf	Tel. +49 7251 75-1710 Fax +49 7251 75-1711 sc-mitte-gm@sew-eurodrive.de
	Central Electronics	SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 42 D-76646 Bruchsal	Tel. +49 7251 75-1780 Fax +49 7251 75-1769 sc-mitte-e@sew-eurodrive.de
	North	SEW-EURODRIVE GmbH & Co KG Alte Ricklinger Straße 40-42 D-30823 Garbsen (near Hannover)	Tel. +49 5137 8798-30 Fax +49 5137 8798-55 sc-nord@sew-eurodrive.de
	East	SEW-EURODRIVE GmbH & Co KG Dankritzer Weg 1 D-08393 Meerane (near Zwickau)	Tel. +49 3764 7606-0 Fax +49 3764 7606-30 sc-ost@sew-eurodrive.de
	South	SEW-EURODRIVE GmbH & Co KG Domagkstraße 5 D-85551 Kirchheim (near München)	Tel. +49 89 909552-10 Fax +49 89 909552-50 sc-sued@sew-eurodrive.de
	West	SEW-EURODRIVE GmbH & Co KG Siemensstraße 1 D-40764 Langenfeld (near Düsseldorf)	Tel. +49 2173 8507-30 Fax +49 2173 8507-55 sc-west@sew-eurodrive.de
	Drive Service Hotline / 24 Hour Service		+49 180 5 SEWHELP +49 180 5 7394357
	Additional addresses for service in Germany provided on request!		
France			
Production Sales Service	Haguenau	SEW-USOCOME 48-54, route de Soufflenheim B. P. 20185 F-67506 Haguenau Cedex	Tel. +33 3 88 73 67 00 Fax +33 3 88 73 66 00 http://www.usocomme.com sew@usocomme.com
Assembly Sales Service	Bordeaux	SEW-USOCOME Parc d'activités de Magellan 62, avenue de Magellan - B. P. 182 F-33607 Pessac Cedex	Tel. +33 5 57 26 39 00 Fax +33 5 57 26 39 09
	Lyon	SEW-USOCOME Parc d'Affaires Roosevelt Rue Jacques Tati F-69120 Vaulx en Velin	Tel. +33 4 72 15 37 00 Fax +33 4 72 15 37 15
	Paris	SEW-USOCOME Zone industrielle 2, rue Denis Papin F-77390 Verneuil l'Etang	Tel. +33 1 64 42 40 80 Fax +33 1 64 42 40 88
Additional addresses for service in France provided on request!			
Algeria			
Sales	Alger	Réducom 16, rue des Frères Zaghoun Bellevue El-Harrach 16200 Alger	Tel. +213 21 8222-84 Fax +213 21 8222-84
Argentina			
Assembly Sales Service	Buenos Aires	SEW EURODRIVE ARGENTINA S.A. Centro Industrial Garin, Lote 35 Ruta Panamericana Km 37,5 1619 Garin	Tel. +54 3327 4572-84 Fax +54 3327 4572-21 sewar@sew-eurodrive.com.ar



Australia			
Assembly Sales Service	Melbourne	SEW-EURODRIVE PTY. LTD. 27 Beverage Drive Tullamarine, Victoria 3043	Tel. +61 3 9933-1000 Fax +61 3 9933-1003 http://www.sew-eurodrive.com.au enquires@sew-eurodrive.com.au
	Sydney	SEW-EURODRIVE PTY. LTD. 9, Sleigh Place, Wetherill Park New South Wales, 2164	Tel. +61 2 9725-9900 Fax +61 2 9725-9905 enquires@sew-eurodrive.com.au
Austria			
Assembly Sales Service	Wien	SEW-EURODRIVE Ges.m.b.H. Richard-Strauss-Strasse 24 A-1230 Wien	Tel. +43 1 617 55 00-0 Fax +43 1 617 55 00-30 http://sew-eurodrive.at sew@sew-eurodrive.at
Belgium			
Assembly Sales Service	Brüssel	SEW Caron-Vector S.A. Avenue Eiffel 5 B-1300 Wavre	Tel. +32 10 231-311 Fax +32 10 231-336 http://www.caron-vector.be info@caron-vector.be
Brazil			
Production Sales Service	Sao Paulo	SEW-EURODRIVE Brasil Ltda. Avenida Amâncio Gaiolli, 50 Caixa Postal: 201-07111-970 Guarulhos/SP - Cep.: 07251-250	Tel. +55 11 6489-9133 Fax +55 11 6480-3328 http://www.sew.com.br sew@sew.com.br
	Additional addresses for service in Brazil provided on request!		
Bulgaria			
Sales	Sofia	BEVER-DRIVE GmbH Bogdanovetz Str.1 BG-1606 Sofia	Tel. +359 2 9532565 Fax +359 2 9549345 bever@fastbg.net
Cameroon			
Sales	Douala	Electro-Services Rue Drouot Akwa B.P. 2024 Douala	Tel. +237 4322-99 Fax +237 4277-03
Canada			
Assembly Sales Service	Toronto	SEW-EURODRIVE CO. OF CANADA LTD. 210 Walker Drive Bramalea, Ontario L6T3W1	Tel. +1 905 791-1553 Fax +1 905 791-2999 http://www.sew-eurodrive.ca l.reynolds@sew-eurodrive.ca
	Vancouver	SEW-EURODRIVE CO. OF CANADA LTD. 7188 Honeyman Street Delta. B.C. V4G 1 E2	Tel. +1 604 946-5535 Fax +1 604 946-2513 b.wake@sew-eurodrive.ca
	Montreal	SEW-EURODRIVE CO. OF CANADA LTD. 2555 Rue Leger Street LaSalle, Quebec H8N 2V9	Tel. +1 514 367-1124 Fax +1 514 367-3677 a.peluso@sew-eurodrive.ca
	Additional addresses for service in Canada provided on request!		
Chile			
Assembly Sales Service	Santiago de Chile	SEW-EURODRIVE CHILE LTDA. Las Encinas 1295 Parque Industrial Valle Grande LAMP RCH-Santiago de Chile P.O. Box Casilla 23 Correo Quilicura - Santiago - Chile	Tel. +56 2 75770-00 Fax +56 2 75770-01 ventas@sew-eurodrive.cl
China			
Production Assembly Sales Service	Tianjin	SEW-EURODRIVE (Tianjin) Co., Ltd. No. 46, 7th Avenue, TEDA Tianjin 300457	Tel. +86 22 25322612 Fax +86 22 25322611 gm-tianjin@sew-eurodrive.cn http://www.sew.com.cn



Address List

China			
Assembly Sales Service	Suzhou	SEW-EURODRIVE (Suzhou) Co., Ltd. 333, Suhong Middle Road Suzhou Industrial Park Jiangsu Province, 215021 P. R. China	Tel. +86 512 62581781 Fax +86 512 62581783 suzhou@sew.com.cn
Colombia			
Assembly Sales Service	Bogotá	SEW-EURODRIVE COLOMBIA LTDA. Calle 22 No. 132-60 Bodega 6, Manzana B Santafé de Bogotá	Tel. +57 1 54750-50 Fax +57 1 54750-44 sewcol@sew-eurodrive.com.co
Croatia			
Sales Service	Zagreb	KOMPEKS d. o. o. PIT Erdödy 4 II HR 10 000 Zagreb	Tel. +385 1 4613-158 Fax +385 1 4613-158 kompeks@net.hr
Czech Republic			
Sales	Praha	SEW-EURODRIVE CZ S.R.O. Business Centrum Praha Luná 591 CZ-16000 Praha 6 - Vokovice	Tel. +420 220121236 Fax +420 220121237 http://www.sew-eurodrive.cz sew@sew-eurodrive.cz
Denmark			
Assembly Sales Service	Kopenhagen	SEW-EURODRIVEA/S Geminivej 28-30, P.O. Box 100 DK-2670 Greve	Tel. +45 43 9585-00 Fax +45 43 9585-09 http://www.sew-eurodrive.dk sew@sew-eurodrive.dk
Estonia			
Sales	Tallin	ALAS-KUUL AS Paldiski mnt.125 EE 0006 Tallin	Tel. +372 6593230 Fax +372 6593231 veiko.soots@alas-kuul.ee
Finland			
Assembly Sales Service	Lahti	SEW-EURODRIVE OY Vesimäentie 4 FIN-15860 Hollola 2	Tel. +358 201 589-300 Fax +358 3 780-6211 http://www.sew-eurodrive.fi sew@sew.fi
Gabon			
Sales	Libreville	Electro-Services B.P. 1889 Libreville	Tel. +241 7340-11 Fax +241 7340-12
Great Britain			
Assembly Sales Service	Normanton	SEW-EURODRIVE Ltd. Beckbridge Industrial Estate P.O. Box No.1 GB-Normanton, West- Yorkshire WF6 1QR	Tel. +44 1924 893-855 Fax +44 1924 893-702 http://www.sew-eurodrive.co.uk info@sew-eurodrive.co.uk
Greece			
Sales Service	Athen	Christ. Boznos & Son S.A. 12, Mavromichali Street P.O. Box 80136, GR-18545 Piraeus	Tel. +30 2 1042 251-34 Fax +30 2 1042 251-59 http://www.boznos.gr info@boznos.gr
Hong Kong			
Assembly Sales Service	Hong Kong	SEW-EURODRIVE LTD. Unit No. 801-806, 8th Floor Hong Leong Industrial Complex No. 4, Wang Kwong Road Kowloon, Hong Kong	Tel. +852 2 7960477 + 79604654 Fax +852 2 7959129 sew@sewhk.com



Hungary			
Sales Service	Budapest	SEW-EURODRIVE Kft. H-1037 Budapest Kunigunda u. 18	Tel. +36 1 437 06-58 Fax +36 1 437 06-50 office@sew-eurodrive.hu
India			
Assembly Sales Service	Baroda	SEW-EURODRIVE India Pvt. Ltd. Plot No. 4, Gidc Por Ramangamdi · Baroda - 391 243 Gujarat	Tel. +91 265 2831086 Fax +91 265 2831087 mdoffice@seweurodriveindia.com
Technical Offices	Bangalore	SEW-EURODRIVE India Private Limited 308, Prestige Centre Point 7, Edward Road Bangalore	Tel. +91 80 22266565 Fax +91 80 22266569 salesbang@seweurodriveinindia.com
	Mumbai	SEW-EURODRIVE India Private Limited 312 A, 3rd Floor, Acme Plaza Andheri Kurla Road, Andheri (E) Mumbai	Tel. +91 22 28348440 Fax +91 22 28217858 salesmumbai@seweurodriveindia.com
Ireland			
Sales Service	Dublin	Alperion Engineering Ltd. 48 Moyle Road Dublin Industrial Estate Glasnevin, Dublin 11	Tel. +353 1 830-6277 Fax +353 1 830-6458
Israel			
Sales	Tel-Aviv	Liraz Handasa Ltd. Ahofer Str 34B / 228 58858 Holon	Tel. +972 3 5599511 Fax +972 3 5599512 lirazhandasa@barak-online.net
Italy			
Assembly Sales Service	Milano	SEW-EURODRIVE di R. Blickle & Co.s.a.s. Via Bernini,14 I-20020 Solaro (Milano)	Tel. +39 02 96 9801 Fax +39 02 96 799781 sewit@sew-eurodrive.it
Ivory Coast			
Sales	Abidjan	SICA Ste industrielle et commerciale pour l'Afrique 165, Bld de Marseille B.P. 2323, Abidjan 08	Tel. +225 2579-44 Fax +225 2584-36
Japan			
Assembly Sales Service	Toyoda-cho	SEW-EURODRIVE JAPAN CO., LTD 250-1, Shimoman-no, Iwata Shizuoka 438-0818	Tel. +81 538 373811 Fax +81 538 373814 sewjapan@sew-eurodrive.co.jp
Korea			
Assembly Sales Service	Ansan-City	SEW-EURODRIVE KOREA CO., LTD. B 601-4, Banweol Industrial Estate Unit 1048-4, Shingil-Dong Ansan 425-120	Tel. +82 31 492-8051 Fax +82 31 492-8056 master@sew-korea.co.kr
Latvia			
Sales	Riga	SIA Alas-Kuul Katlakalna 11C LV-1073 Riga	Tel. +371 7139386 Fax +371 7139386 info@alas-kuul.ee
Lebanon			
Sales	Beirut	Gabriel Acar & Fils sarl B. P. 80484 Bourj Hammoud, Beirut	Tel. +961 1 4947-86 +961 1 4982-72 +961 3 2745-39 Fax +961 1 4949-71 gacar@beirut.com



Address List

Lithuania			
Sales	Alytus	UAB Irseva Merkines g. 2A LT-62252 Alytus	Tel. +370 315 79204 Fax +370 315 56175 info@irseva.lt www.sew-eurodrive.lt
Luxembourg			
Assembly Sales Service	Brüssel	CARON-VECTOR S.A. Avenue Eiffel 5 B-1300 Wavre	Tel. +32 10 231-311 Fax +32 10 231-336 http://www.caron-vector.be info@caron-vector.be
Malaysia			
Assembly Sales Service	Johore	SEW-EURODRIVE SDN BHD No. 95, Jalan Seroja 39, Taman Johor Jaya 81000 Johor Bahru, Johor West Malaysia	Tel. +60 7 3549409 Fax +60 7 3541404 kchtan@pd.jaring.my
Mexico			
Assembly Sales Service	Queretaro	SEW-EURODRIVE, Sales and Distribution, S. A. de C. V. Privada Tequisquiapan No. 102 Parque Ind. Queretaro C. P. 76220 Queretaro, Mexico	Tel. +52 442 1030-300 Fax +52 442 1030-301 scmexico@seweurodrive.com.mx
Morocco			
Sales	Casablanca	S. R. M. Société de Réalisations Mécaniques 5, rue Emir Abdelkader 05 Casablanca	Tel. +212 2 6186-69 + 6186-70 + 6186-71 Fax +212 2 6215-88 srm@marocnet.net.ma
Netherlands			
Assembly Sales Service	Rotterdam	VECTOR Aandrijftechniek B.V. Industrieweg 175 NL-3044 AS Rotterdam Postbus 10085 NL-3004 AB Rotterdam	Tel. +31 10 4463-700 Fax +31 10 4155-552 http://www.vector.nu info@vector.nu
New Zealand			
Assembly Sales Service	Auckland	SEW-EURODRIVE NEW ZEALAND LTD. P.O. Box 58-428 82 Greenmount drive East Tamaki Auckland	Tel. +64 9 2745627 Fax +64 9 2740165 sales@sew-eurodrive.co.nz
	Christchurch	SEW-EURODRIVE NEW ZEALAND LTD. 10 Settlers Crescent, Ferrymead Christchurch	Tel. +64 3 384-6251 Fax +64 3 384-6455 sales@sew-eurodrive.co.nz
Norway			
Assembly Sales Service	Moss	SEW-EURODRIVE A/S Solgaard skog 71 N-1599 Moss	Tel. +47 69 241-020 Fax +47 69 241-040 sew@sew-eurodrive.no
Peru			
Assembly Sales Service	Lima	SEW DEL PERU MOTORES REDUCTORES S.A.C. Los Calderos, 120-124 Urbanizacion Industrial Vulcano, ATE, Lima	Tel. +51 1 3495280 Fax +51 1 3493002 sewperu@sew-eurodrive.com.pe
Poland			
Assembly Sales Service	Lodz	SEW-EURODRIVE Polska Sp.z.o.o. ul. Techniczna 5 PL-92-518 Lodz	Tel. +48 42 67710-90 Fax +48 42 67710-99 http://www.sew-eurodrive.pl sew@sew-eurodrive.pl



Portugal			
Assembly Sales Service	Coimbra	SEW-EURODRIVE, LDA. Apartado 15 P-3050-901 Mealhada	Tel. +351 231 20 9670 Fax +351 231 20 3685 http://www.sew-eurodrive.pt infosew@sew-eurodrive.pt
Romania			
Sales Service	Bucuresti	Sialco Trading SRL str. Madrid nr.4 011785 Bucuresti	Tel. +40 21 230-1328 Fax +40 21 230-7170 sialco@sialco.ro
Russia			
Sales	St. Petersburg	ZAO SEW-EURODRIVE P.O. Box 263 RUS-195220 St. Petersburg	Tel. +7 812 5357142 +812 5350430 Fax +7 812 5352287 http://www.sew-eurodrive.ru sew@sew-eurodrive.ru
Senegal			
Sales	Dakar	SENEMECA Mécanique Générale Km 8, Route de Rufisque B.P. 3251, Dakar	Tel. +221 849 47-70 Fax +221 849 47-71 senemeca@sentoo.sn
Serbia and Montenegro			
Sales	Beograd	DIPAR d.o.o. Kajmakcalanska 54 SCG-11000 Beograd	Tel. +381 11 3088677 / +381 11 3088678 Fax +381 11 3809380 dipar@yubc.net
Singapore			
Assembly Sales Service	Singapore	SEW-EURODRIVE PTE. LTD. No 9, Tuas Drive 2 Jurong Industrial Estate Singapore 638644	Tel. +65 68621701 Fax +65 68612827 sewsingapore@sew-eurodrive.com
Slovakia			
Sales	Sered	SEW-Eurodrive SK s.r.o. Trnavska 920 SK-926 01 Sered	Tel. +421 31 7891311 Fax +421 31 7891312 sew@sew-eurodrive.sk
Slovenia			
Sales Service	Celje	Pakman - Pogonska Tehnika d.o.o. Ul. XIV. divizije 14 SLO – 3000 Celje	Tel. +386 3 490 83-20 Fax +386 3 490 83-21 pakman@siol.net
South Africa			
Assembly Sales Service	Johannesburg	SEW-EURODRIVE (PROPRIETARY) LIMITED Eurodrive House Cnr. Adcock Ingram and Aerodrome Roads Aeroton Ext. 2 Johannesburg 2013 P.O.Box 90004 Bertsham 2013	Tel. +27 11 248-7000 Fax +27 11 494-3104 dross@sew.co.za
	Capetown	SEW-EURODRIVE (PROPRIETARY) LIMITED Rainbow Park Cnr. Racecourse & Omuramba Road Montague Gardens Cape Town P.O.Box 36556 Chempet 7442 Cape Town	Tel. +27 21 552-9820 Fax +27 21 552-9830 Telex 576 062 dswanepoel@sew.co.za
	Durban	SEW-EURODRIVE (PROPRIETARY) LIMITED 2 Monaceo Place Pinetown Durban P.O. Box 10433, Ashwood 3605	Tel. +27 31 700-3451 Fax +27 31 700-3847 dtait@sew.co.za



Address List

Spain			
Assembly Sales Service	Bilbao	SEW-EURODRIVE ESPAÑA, S.L. Parque Tecnológico, Edificio, 302 E-48170 Zamudio (Vizcaya)	Tel. +34 9 4431 84-70 Fax +34 9 4431 84-71 sew.spain@sew-eurodrive.es
Sweden			
Assembly Sales Service	Jönköping	SEW-EURODRIVE AB Gnejsvägen 6-8 S-55303 Jönköping Box 3100 S-55003 Jönköping	Tel. +46 36 3442-00 Fax +46 36 3442-80 http://www.sew-eurodrive.se info@sew-eurodrive.se
Switzerland			
Assembly Sales Service	Basel	Alfred Imhof A.G. Jurastrasse 10 CH-4142 Münchenstein bei Basel	Tel. +41 61 41717-17 Fax +41 61 41717-00 http://www.imhof-sew.ch info@imhof-sew.ch
Thailand			
Assembly Sales Service	Chon Buri	SEW-EURODRIVE (Thailand) Ltd. Bangpakong Industrial Park 2 700/456, Moo.7, Tambol Donhuaroh Muang District Chon Buri 20000	Tel. +66 38 454281 Fax +66 38 454288 sewthailand@sew-eurodrive.co.th
Tunisia			
Sales	Tunis	T. M.S. Technic Marketing Service 7, rue Ibn El Heithem Z.I. SMMT 2014 Mégrine Erriadh	Tel. +216 1 4340-64 + 1 4320-29 Fax +216 1 4329-76
Turkey			
Assembly Sales Service	Istanbul	SEW-EURODRIVE Hareket Sistemleri Sirketi Bagdat Cad. Koruma Cikmazi No. 3 TR-34846 Maltepe ISTANBUL	Tel. +90 216 4419163 + 216 4419164 + 216 3838014 Fax +90 216 3055867 sew@sew-eurodrive.com.tr
Ukraine			
Sales Service	Dnepropetrovsk	SEW-EURODRIVE Str. Rabochaja 23-B, Office 409 49008 Dnepropetrovsk	Tel. +380 56 370 3211 Fax +380 56 372 2078 m.piatnitsa@sew-eurodrive.de
USA			
Production Assembly Sales Service	Greenville	SEW-EURODRIVE INC. 1295 Old Spartanburg Highway P.O. Box 518 Lyman, S.C. 29365	Tel. +1 864 439-7537 Fax Sales +1 864 439-7830 Fax Manuf. +1 864 439-9948 Fax Ass. +1 864 439-0566 Telex 805 550 http://www.seweurodrive.com cslyman@seweurodrive.com
Assembly Sales Service	San Francisco	SEW-EURODRIVE INC. 30599 San Antonio St. Hayward, California 94544-7101	Tel. +1 510 487-3560 Fax +1 510 487-6381 cshayward@seweurodrive.com
	Philadelphia/PA	SEW-EURODRIVE INC. Pureland Ind. Complex 2107 High Hill Road, P.O. Box 481 Bridgeport, New Jersey 08014	Tel. +1 856 467-2277 Fax +1 856 845-3179 csbridgeport@seweurodrive.com
	Dayton	SEW-EURODRIVE INC. 2001 West Main Street Troy, Ohio 45373	Tel. +1 937 335-0036 Fax +1 937 440-3799 cstroy@seweurodrive.com
	Dallas	SEW-EURODRIVE INC. 3950 Platinum Way Dallas, Texas 75237	Tel. +1 214 330-4824 Fax +1 214 330-4724 csdallas@seweurodrive.com
Additional addresses for service in the USA provided on request!			



Venezuela			
Assembly Sales Service	Valencia	SEW-EURODRIVE Venezuela S.A. Av. Norte Sur No. 3, Galpon 84-319 Zona Industrial Municipal Norte Valencia, Estado Carabobo	Tel. +58 241 832-9804 Fax +58 241 838-6275 sewventas@cantv.net sewfinanzas@cantv.net

How we're driving the world

With people who think fast and develop the future with you.



With a global presence that offers responsive and reliable solutions. Anywhere.


With a worldwide service network that is always close at hand.

With drives and controls that automatically improve your productivity.



With innovative technology that solves tomorrow's problems today.

With comprehensive knowledge in virtually every branch of industry today.



With online information and software updates, via the Internet, available around the clock.

With uncompromising quality that reduces the cost and complexity of daily operations.

SEW-EURODRIVE
Driving the world



SEW
EURODRIVE

SEW-EURODRIVE GmbH & Co KG
P.O. Box 3023 · D-76642 Bruchsal / Germany
Phone +49 7251 75-0 · Fax +49 7251 75-1970
sew@sew-eurodrive.com

→ www.sew-eurodrive.com